

BÜFA Hånddoseringspumpe 1000

Spare Parts List for the Resin Pump

Serial no.	Designation	Material	Quantity
1000-01	Suction pipe	Alu.	1
1000-02	Suction hose	PE	1
1000-04	Suction valve, complete	PP/glass/stainless steel	1
1000-05	Valve ball	Glass 14 mm	1
1000-06	Spring	Stainless steel	1
1000-07	Valve housing	PP	1
1000-08	Discharge elbow	PP	1
1000-09	Discharge valve, complete	PP/glass/stainless steel	1
1000-10	Bottom flange	PP	1
1000-11	Nut M10	Stainless steel	1
1000-12	Plain washer 10 mm	Stainless steel	2
1000-13	Piston head and bottom piece	Alu.	2
1000-14	Piston rings	PTFE / stainless steel	2
1000-15	Piston middel piece	Alu.	1
1000-16	Cylinder	Glass	1
1000-17	Sealing profile	PTFE	2
1000-18	Upper flange	PP	1
1000-19	Toothed rack	Stainless steel	1
1000-20	Spur wheel	Galvanized steel	1
1000-21	Impeller	PA	1
1000-22	O-ring	Viton	1
1000-23	Crank handle bearing	PA	2
1000-26	Mounting	Alu.	1
1000-27	Crank handle	Plastic	1
1000-32	Connecting rod	Galvanized steel	3
1000-33	Drive shaft	Steel	1
1000-35	Crank arm	Galvanized steel	1
1000-36	Roller shaft	Galvanized steel	1
1000-37	Replacement pump, complete unit		1

15.12.2008

